Techtalk 173

| March 2018



FAQ ON THE USE OF DURADEK WITH PEDESTALS AND PROTECTION LAYERS

DURADEK ULTRA

Roof Membrane can be either left exposed to the elements or be overlaid with a protection layer. We have had many enquires about where to find pedestals and protection layers.



BELOW IS A SHORT LIST OF PEDESTAL AND **DRAINAGE MAT SUPPLIERS:**

Adjustable Roof Paver Pedestals: allows tiles to be installed dead flat even when the existing deck slope is greater than 1/4" in 12"

- Apian Way System: www.appianwaysystem.com
- Bisonip: www.bisonip.com
- Wausau Paving: www.wausaupaving.com/...
- Westile: www.westile.com/pedestal.php



- Enviro Spec Inc: www.envirospecinc.com
- Westile: www.westile.com/pedestal.php

Drainage boards/mats: primarily used under interlocking stone, precast pavers and poured concrete overlays

- Building Systems: www.buildingsystems.basf.com/...
- Vast Pavers: <u>www.vastpavers.com</u>

Please Note:

- Overlays will add a minimum of 3" to the height of the deck assembly. The structure must be designed to accept the additional assembly heights, especially at door openings.
- Duradek wall flashing membrane must extend minimum 6" above the height of the finished deck overlay.
- Overlays' dead weight can be substantial. The structure must be engineered (by others) to accept the weight of the system considered.



Wood Deck Panels: 5-10 psf Concrete Pavers: 15-25 psf Interlocking Stone: 20-30 psf

Poured Concrete: 20-30 psf or more * Composite products are usually lighter









Products described in this bulletin are not supplied by Duradek. Duradek does not warrant these products or acknowledge the suitability of the product for specific jobs.



